

tack and change to regular stitch, sew the rest of the seam. Press the seam open, just as you would a centered application.

2. Open zipper, on cool setting and with a pressing cloth, press the coil s flat and close the zipper

3. With the seam open and the garment turned to one side, exposing a single thickness of the seam allowance on one side, center the zipper on the basted seam, pinning it in place along the single thickness seam allowance as you go. Repeat on opposite side.

4. **Hand baste** the zipper in place the length of the zipper plus  $\frac{1}{2}$ ". *Important do not go more than  $\frac{1}{2}$ " past the end of the zipper.* Expose seam allowance on opposite side, repeat basting.

5. Remove the **machine** basting to open up the seam

6. Unzip the zipper. From the bottom of the zipper, on the inside of the garment, feed the hemostat up under the zipper, grab the zipper slide and pull it down to the end of the zipper.

7. Use a regular, one-sided zipper foot to sew <sup>r</sup>very close to the coil. If you have one which is adjustable, the needle should center in the notch, not too close to the inside or the outside. Keeping the zipper coil perpendicular to the fabric, stitch *slightly* past the end of the zipper

8. Pull the zipper slide up to close the zipper in one smooth motion.

9. Hand sew a bar tack at the end of the zipper and cut off the excess coil.